ΗΙΟΚΙ

WIRELESS MINI LOGGER LR8512, LR8513, LR8514, LR8515



For easy-to-use loggers, look no further!

Connect to a tablet, smartphone, or PC for easy, wireless data collection

CE 😣 Bluetooth

Countries and regions where wireless operation is currently supported: Japan, U.S.A., Canada, EU, Norway, Switzerland, Turkey, Russia, Singapore, Vietnam, India, Australia, New Zealand, and Chile As of November 2015. For an updated list, please visit the HIOKI website at www.hioki.com.

Connect to a tablet, smartphone, or PC for easy, wireless data collection

Use your tablet or PC to collect data even as signals are being logged. Check data immediately and on-site.

No more complicated logger registration. Just touch to detect, and touch to register.



Tablet, Smartphone

Android Terminal

Operating procedure

Setting and measurement Use your Android terminal to set and send measurement conditions, such as the recording interval, to the logger to begin measurement. "Settings cannot be changed directly on the logger.

Data collection

Collect the data recorded in the logger after or even during measurement.

Data analysis

Connect a USB cable to transfer the data to a PC. Use the bundled software, "Logger Utility," to perform analysis.

Specifications

Supported devices Android tablet / Android smartphone

Communications	Bluetooth*2.1 + EDR
Android OS	4.0.3 or later
Number of available registrations	Max. 100 units
Recommended display size	7 inches or larger
Software	Collection: Wireless Logger Collector for Android Analysis: Logger Utility (PC)
Software acquisition	Collection: Download from Google Play Analysis: Supplied CD-R / Download from HIOKI's website





Setting screens



Measure Settings Title Comment Identifier Name Recording Interval 500m Cottinuous Cottinuous Cottinuous Alarm

Waveform monitoring

Even during measurement, you can check recent data trends in waveform and values. This is also convenient for checking the levels before actual recording.

Portable and convenient

The user interface is perfect for the small screens of tablets or smartphones.

Check waveforms on-site

You can check the collected data on your tablet or smartphone.

Computer Windows PC

Operating procedure

Setting and measurement

Use your Windows PC to set and send measurement conditions, such as the recording interval, to the logger to begin measurement. *Settings cannot be changed directly on the logger.


Data collection

Collect the data recorded in the logger after or even during measurement.

Data analysis

Start "Logger Utility" and perform analysis at the touch of a button.

Specifications



Periodic collection

You can automatically collect data at intervals from 10 minutes to 1 day. Avoid the trouble of going around to collect data.

Status monitoring

You can periodically monitor information such as the latest measurement, remaining battery power, and signal strength.

Multi-device management

Centrally manage up to 100 loggers. Since you can group devices in a tree structure, management is very easy.





Here's why the "WIRELESS MINI" is for you

Select from 4 types to match your application.

All models have 2 channels, with built-in high-capacity memory for long-term recording. Compact and space-saving, the mini loggers can be easily installed in locations where wiring is difficult.



Wireless

30 m line-of-sight, up to 100 devices

Built-in Bluetooth® wireless technology.

Communication reaches 30 m, line of-sight. (This varies depending on the performance of the communicating tablet or PC.) Manage up to 100 devices.




Make measurements inside panels or other difficult-to-wire locations

Installing a data logger in a switchboard or control panel has never been easier. Gone is the need to feed wiring through the paneldata collection is done wirelessly so you can close the panel door for safe measurements.

The loggers are also useful for measuring in difficult-to-wire locations, like high places or on moving machines.

Automatic synthesis of acquired data into a single piece of data

No matter what time during measurement you collect the data, data is automatically merged together into one single file. You don't need to manually synthesize data.



Compact with Built-in High-capacity Memory

Install in tight spaces

Pocket size for installation anywhere. Use the optional MAGNETIC STRAP to hang it on a wall - solving all of your installation space problems.



Despite their compact size, the mini loggers' built-in high-capacity memory offers plenty of space for you to perform long-term recording with peace of mind.

Recording intervals	Recordable time		
0.1 sec	13 hr, 53 min, 20 sec		
0.2 sec	1 day, 3 hr, 46 min, 40 sec		
0.5 sec	2 days, 21 hr, 26 min, 40 sec		
1 sec	5 days, 18 hr, 53 min, 20 sec		
2 sec	11 days, 13 hr, 46 min, 40 sec		
5 sec	28 days, 22 hr, 26 min, 40 sec		
10 sec	57 days, 20 hr, 53 min, 20 sec		
20 sec	115 days, 17 hr, 46 min, 40 sec		
30 sec	173 days, 14 hr, 40 min, 00 sec		
1 min	347 days, 5 hr, 20 min, 00 sec		
2 min to 60 min	Over 365 days		

Power-saving Design

Power-saving function for longer battery life

Set to turn on the Bluetooth® only during a pre-set time period. The shorter the power is on, the longer the battery will last.

If recording for a long p	eriod of time,	we recommen	ha using the A	CADAPTER.

LR8512	LR8513	LR8514	LR8515
2 months	3 months	3.5 months	2.5 months
2 months	1 months	3 months	10 days
14 days	10 days	20 days	7 days
	2 months 2 months	2 months 3 months 2 months 1 months	2 months 3 months 3.5 months 2 months 1 months 3 months


When Bluetooth® is constantly on or constantly off.

When using the free run function, the continuous operating time is the same as when using a recording interval of 1 sec., even when measurement is stopped.

2 channels built in all models

All models have 2-channels built in, so you can measure 2 locations simultaneously.


With the LR8515, you can measure both voltage and temperature with a single device.



Selectable recording modes

One time recording: Once the memory is full, the logger stops recording. Prevents data from being overwritten and protects important data.

Endless recording: Once the memory is full, the logger begins overwriting old data. You can always keep the latest 500,000 pieces of data.



NEW **Free Run**

Excluding LR8512

Update the current value display even while measurement is stopped ON/ OFF selection

The measurement value is indicated every 1 second while measurement is stopped. (the data is not saved in the memory.) The measurement value is saved in the memory every recording interval and indicated every 1 second regardless of recording interval setting while measuring.

(when the setting of recording interval is less than 1 second, the measurement value is indicated every recording interval)

WIRELESS PULSE LOGGER LR8512



For applications such as:

Air conditioning (flow rate), automobiles (flow rate, vehicle speed), cogeneration (flow rate)

200 µs or higher when the filter is set to OFF

100 ms or higher when the filter is set to ON

(must be 100 µs or higher in H period and L period.)

(must be 50 ms or higher in H period and L period.)

Max. Resolution

1 nulse

1/n [r/s]

Easily manage and record flow rates

Pulse input

Pulse input

Measurement

Totalization

No. of revolutions

obiects

cycle

Record and manage flow rates for liquids such as water, gas, and petroleum. You can measure the flow meter's output signal (pulse) to visualize daily fluctuations.



Specifications (Accuracy guaranteed and Post-adjustment accuracy guaranteed for 1 year) No. of input 2 1 1 (CNID

channels	2 channels (common GND)	
Measurement modes	Integrating (cumulative/Instant), Revolution, Logic (Records an 1/0 for each recording interval)	
Supported input format	Non-voltage "a" contact (always-open contact point), open collector, or voltage input (DC 0 V to 50 V)	
Recording intervals	0.1 to 30 sec, 1 to 60 min, 16 selections	
Recording modes	Instantaneous value	
Dimensions,	85W×61H×31D mm (3.35W×2.40H×1.22D in),	
Weight	95 g (Not including the battery)	

Models and accessories +AC Adapter is not included.

WIRELESS PULSE LOGGER LR8512

Accessories: CD-R (Instruction Manual, Logger Utility, Wireless Logger Collector) × 1, Measurement Guide ×1, Caution for Using Radio Waves × 1, AA alkaline batteries (LR6) ×2 Connection Cable L1010 × 2



Range

1000M pulse f.s.

5000/n [r/s] f.s.

*n is the number of pulses, 1 to 1000, per revolution.





AC ADAPTER Z2003 100 to 240 VAC. 50/60Hz



Measurement Range

0

0

to 1000 M pulse

to 5000/n [r/s]



Supports voltage input and thermocouple types K and T with a single device

WIRELESS VOLTAGE/ TEMP LOGGER LR8515



For applications such as: Various tests for electronics/automobiles/transportation,

PV maintenance

additional purchase

Record voltage and temperature with a single device

You can use a single device to measure everything from the minute voltages of pyranometers or heat flow sensors to battery voltage.

Also view the correlation between voltage and temperature.

Measurement ranges

No. of input channels 2 ch (isolated; select voltage of thermocouple for each channel	
Measurement items	Voltage/Thermocouple (K, T)
Input terminals	M3 screw type terminal block (2 terminals per channel)
Maximum input voltage	DC±50 V
Max. inter-channel voltage	DC 70 V
Recording intervals	0.1 to 30 sec, 1 to 60 min, 16 selections
Recording modes	Instantaneous value
Dimensions, Weight	85W×75H×38D mm (3.35W×2.95H×1.50D in), 126 g (Not including the battery)

Specifications (Accuracy guaranteed and Post-adjustment accuracy guaranteed for 1 year)

Models and accessories *Thermocouples and AC Adapter are not included. WIRELESS VOLTAGE/TEMP LOGGER LR8515

Accessories: CD-R (Instruction Manual, Logger Utility, Wireless Logger Collector) × 1, $Measurement\,Guide \times 1, Caution\,for\,Using\,Radio\,Waves \times 1, AA\,alkaline\,batteries$ (LR6)×2

Measurement objects		Range	Max. Resolution	Measurable Range		Measurement Accuracy
		50 mV f.s.	0.01 mV	-50 mV	to 50 mV	±0.05 mV
Vallaria		500 mV f.s.	0.1 mV	-500 mV	to 500 mV	±0.5 mV
Voltage		5 V f.s.	1 mV	-5 V	to 5 V	±5 mV
		50 V f.s.	10 mV	-50 V	to 50 V	±50 mV
Thermocouples	ĸ	к 1000 °C f.s.	0.1 °C	-200 °C	to -100 °C	±1.5 °C
	K 1000 °C f.	1000 C I.s.		-100 °C	to 999.9 °C	±0.8 °C
			0.1 °C	-200 °C	to -100 °C	±1.5 °C
	T 10	1000 °C f.s.		-100 °C	to 0 °C	±0.8 °C
				0 °C	to 400 °C	±0.6 °C

Reference junction compensation: Switchable between internal and external Reference junction compensation accuracy: $\pm 0.5^{\circ}C$ (When using internal compensation, add to thermocouple measurement accuracy.) Temperature characteristics: Add (measurement accuracy × 0.1)/°C to measurement accuracy.

Options





WIRELESS CLAMP LOGGER LR8513



For applications such as:

PV maintenance, automobile tests, forklifts, railroads, equipment maintenance

Built-in average value and maximum value recording modes

The logger can record the average or maximum value for each recording interval using RMS values measured at a 0.5 sec. interval. Average and maximum values are useful when assessing 30 min. demand and peak leakage current, respectively.

Simple electrical measurement

Set the voltage and power factor for simple electrical measurements. Direct reading on this device is possible for single-phase, two-wire systems.

sing 30 min. demand and peak je current, respectively.	REC D D	15.00					
Current sensor specifications							

■ Specifications (Accuracy guaranteed and Post-adjustment accuracy guaranteed for 1 year)


No. of input channels	2 channels (common GND)	
Measurement items	AC load current, DC load current AC leak current (using current sensor)	
Effective value calculation	Software calculates the true RMS value	
Measurement ranges	AC500.0 mA to 2000 A (with current sensor) DC10.00 A to 2000 A (with current sensor) *Current and leak current that occur intermittently cannot be measured.	
Measurement accuracy	±0.5% rdg.±5 dgt. (DC, AC 50/60 Hz) *Add the sensor's accuracy when the current sensor is connected	
Recording intervals	0.5 to 30 sec, 1 to 60 min, 14 selections	
Recording modes	Instantaneous value, average value, Maximum value recording	
Dimensions,	85W×75H×38D mm (3. 35W×2.95H×1.50D in) mm,	
Weight 130 g (Not including the battery)		

Models and accessories * Current sensor and AC Adapter are not included.

WIRELESS CLAMP LOGGER LR8513

Accessories: CD-R (Instruction Manual, Logger Utility, Wireless Logger Collector) × 1, Measurement Guide ×1, Caution for Using Radio Waves × 1, AA alkaline batteries (LR6) ×2





SENSOR 9657-10

cord length 3 m (9.84 ft)

040 mm AC 10A

9695-02 Requires the Con-nection Cable 9219

Insulated conductor CLAMP ON SENSOR Not CE Marked φ15 mm, AC 50A

CONNECTION CABLE 9219 For connecting the 9695-02, cord length 3 m (9.84 ft)

SENSOR 9675

φ30 mm AC 10A

cord length 3 m (9.84 ft)

CLAMP ON AC/DC SENSOR CT9691-90, CT9692-90, CT9693-90 CT9691-90: φ35 mm, AC/DC 100A, cord length 2 m (6.56 ft) CT9692-90: φ33 mm, AC/DC 200A, cord length 2 m (6.56 ft) CT9693-90: φ55 mm, AC/DC 2000A, cord length 2 m (6.56 ft)

Shared specifications

LR8512, LR8513, LR8514, LR8515 Control and Bluetooth® 2.1+EDR

MAGNETIC

STRAP Z5004

communications	(Communications range: 30 m, line of sight, security: SSP)
Storage capacity	500,000 data items for each channel
Operating temperature and humidity	Temperature: -20 to 60 °C (-4 to 140 °F), Humidity: 80%rh or less (non-condensing) (Depends on battery and current sensor specifications when they are in use)
Storage temperature and humidity	-20°C to 60°C, 80%rh or less (non-condensing) (With batteries removed)
Functions	Alarm, Scaling, Recording operation hold function, Erroneous operation prevention, Comment recording function, Power saving function, Authentication function, Free Run (excluding LR8512)
Display items	Measurement value, date, time, number of recorded data, maximum value, minimum value, and average value

	Safety	EN61010
	EMC	EN61326 classA, EN61000-3-2, EN61000-3-3
Applicable standards	Wireless certification	Japan: Incorporates a wireless module that has been certified as compliant with applicable technical standards. US: Part 15.247 (Contains FCC ID: QOQWT11IA) Canada:RSS-210 (Contains IC: 5123A-BGTWT11IA) EU: EN 300 328, EN 301 489-1, EN 301 489-17
Vibration	endurance	JIS D 1601:1995 5.3(1), Category 1: Vehicle, Condition: Category A equiv.
	AC adapter	AC ADAPTER Z2003 (sold separately, DC 12 V)
Power	Battery	AA alkaline batteries (LR6) × 2
source	External power	DC 5 V to 13.5 V * can also be supplied from USB bus power, with a conversion cable



WIRELESS HUMIDITY LOGGER LR8514



For applications such as:

Environmental testing, construction, factories, storage, agriculture

The accuracy of values indicated by the * mark is not guaranteed (reference values).

±4%rh

±5%rh

+6%rh

Temperature[°C]

*Only the temperature and humidity sensors affect the measurement accuracy and are subject to calibration. The LR8514 logger does not require calibration.

50

±5%rh

±8%rh*

40

±8%rh*

±6%rh

±5%rh

Conduct surveys and verifications efficiently

100

80

60

40

20

0 0

Relative humidity[%rh]

Easily record and manage the surrounding temperature and humidity. The logger is helpful for status analysis, improvement, and verification. Also, since it can simultaneously record the temperature and humidity in 2 locations, you can compare conditions inside and outside a device. (With 2 sensors installed)

±8%rh*

±6%rh

±5%rh

±3.5%rh

±5%rh

±6%rh

+8%rh

20

±8%rh*

±6%rh*

+10%rh*

±12%rh*

10

■ Humidity measurement accuracy (fig. 1)

±6%rh*

±3%rh

±4%rh

30



Recording temperature and humidity in a server room

±6%rh*

±12%rh*

70

60

±12%rh*

80

Specifications

No. of input channels	2 ch for temperature + 2 ch for humidity (2 sensors can be attached)				
Measurement objects	Temperature, Hum	idity			
Temperature measurement accuracy (using Z2010/Z2011)	±0.5° C (10 °C to 60 °C), using Z2010/Z2011 If outside above temperature range: Add 0.015 °C/ °C (-40 °C to 10 °C) or 0.02° C/ °C (60 °C to 80 °C)				
Humidity measurement accuracy (using Z2010/Z2011)	±3% rh (20 °C to 30 °C, 20% to 90% rh) If outside above range, see Figure 1.				
Recording intervals	0.5 to 30 sec, 1 to 60 min, 14 selections				
Recording modes	Instantaneous value				
Dimensions, Weight	85W×61H×31D mm (3.35W×2.40H×1.22D in), 95 g (Not including the battery)				
Measurement objects	s Range Max. Resolution Measurable Ra				
Temperature	100 °C f.s.	0.1 °C	-40°C	to 80 °C	
Humidity	100%rh f.s.	0.1 %rh	0 %rh	to 100 %rh	

Models and accessories * Temperature and humudity sensor , AC Adapter are not included.

WIRELESS HUMIDITY LOGGER LR8514

Accessories: CD-R (Instruction Manual, Logger Utility, Wireless Logger Collector) × 1, $Measurement \,Guide \times 1, Caution \,for \,Using \,Radio \,Waves \times 1, AA \,alkaline$ batteries (LR6) × 2



MAGNETIC STRAP Z5004



HUMIDITY SENSOR Z2010





Install the WIRELESS MINIs in each place to be measured. Install up to 7 devices.

HIOKI E. E. CORPORATION

81 Koizumi, Ueda, Nagano, 386-1192, Japan TEL +81-268-28-0562 FAX +81-268-28-0568 http://www.hioki.com / E-mail: os-com@hioki.co.jp



to easily carry out observations when irregularities occur.

WIRELESS LOGGING STATION LR8410-20

*For details, see the product catalog.



food (grain) storage, document storage, and art galleries or museums

*For details, see the product catalog.

Registered Trademarks · Bluetooth[®] is a trademark of Bluetooth SIG, Inc. and licensed for use by HIOKI E.E. CORPORATION. Note: Company names and Product names appearing in this catalog are trademarks or registered trademarks of various companies.

DISTRIBUTED BY

HIOKI (Shanghai) SALES & TRADING CO., LTD. TEL +86-21-63910090 EAX +86-21-63910360 http://www.hioki.cn / E-mail: info@hioki.com.cn

HIOKI INDIA PRIVATE LIMITED TEL +91-124-6590210 E-mail: hioki@hioki.in

HIOKI SINGAPORE PTE. LTD. TEL +65-6634-7677 FAX +65-6634-7477 E-mail: info-sg@hioki.com.sg

HIOKI USA CORPORATION

HEADQUARTERS

TEL +1-609-409-9109 FAX +1-609-409-9108 http://www.hiokiusa.com / E-mail: hioki@hiokiusa.com

HIOKI KOREA CO., LTD. TEL +82-2-2183-8847 FAX +82-2-2183-3360 E-mail: info-kr@hioki.co.jp

All information correct as of Nov. 30, 2015. All specifications are subject to change without notice